





IMPORTANT NOTICE FOR MODIFICATIONS ON MODELS CT-3400 AND CT-3460















Time or Alarm Clock Adjustments

User	Transmitter
1. Press and hold the FUNCTION button until a beep is heard	The backlight will turn on the moment the FUNCTION button is pressed.
2. Upon hearing the beep, release the FUNCTION button, 5 0 1 is displayed
3. Press and hold the FUNCTION button once more	
4. Release the FUNCTION button when a beep is heard, 5 0 2 is displayed
5. Press and hold the FUNCTION button once more until a beep is heard,	
6. Release the FUNCTION button 5 0 3 is displayed
7. At that point, press and hold the FUNCTION button until 2 beeps are heard. The hour setting will start to flash.

Pressing the FUNCTION button	
1X Adjust hour (current time)	a. Press the  button to increase the value or to activate or deactivate a function or to toggle through the melodies.
2X Adjust minutes (current time)	b. Press the  to decrease the value or to activate or deactivate a function or to toggle through the melodies.
3X Adjust hour (Alarm)	c. To save modifications, do not touch any buttons for approx 5 to 10 seconds . There will be a beep and the display will return to the time.
4X Adjust minutes (Alarm)	
5X Melody selection for the ringing of the alarm	
6X Activate (ON) / Deactivate (OFF) Alarm	
7X Adjust hour (countdown)	
8X Adjust minutes (countdown)	
9X Melody selection for the countdown	
10X Activate (ON) / Deactivate (OFF) countdown	

Timing Countdown Adjustment

(see "ON PRESS NUMBER" 8 of Alarm and Countdown Adjustment)

Function	By pressing	Icon	Sound	Instructions / description
FOR PARKING COUNTDOWN	 1 st time	 0:10	Melody	10 min parking count down mode
	 2 nd time	 0:20	Melody	20 min parking count down mode
	 3 rd time	 0:30	Melody	30 min parking count down mode
	 4 th time	 1:00	Melody	60 min parking count down mode
	 5 th time	 1:30	Melody	90 min parking count down mode
	 6 th time	 2:00	Melody	120 min parking count down mode
	 7 th time	 0:00	Melody	Parking count down off mode